InstallationInstructions

Multi-tap

ANTRONIX®

Prepare the tap for installation

- 1. Remove hex port plugs and yellow port covers from the tap housing.
- 2. Loosen seizure screws.
- 3. Cut the connector pin to 11/4 in. using the trim guide on the tap housing.
- 4. Install the front portion of the pin connector into the tap housing and hand tighten.
- 5. Complete tightening with an adjustable wrench for a 1/8 to 1/4 turn.
- Tighten the seizure screws to 15 in-lbs.
- 7. Replace the hex port plugs and tighten to 45 in-lbs.

Direct Strand Mounting*

- 1. Loosen the strand clamp assembly and install on strand.
- 2. Slide shrink boot over cables if applicable.
- 3. Position cables and tighten strand clamp to 70 in-lbs.
- 4. Prep the cables for installation according to the manufacturer's specification.
- 5. Complete installation of the cable connector onto the ⁵/₈ x 24 main cable ports by tightening according to the manufacturer's instruction.
- 6. If applicable, slide shrink boot over the entry connector until it touches main part of housing and shrink per manufacturer's guidelines.

Faceplate replacement

- 1. Disconnect all the house drops from the faceplate's F-ports.
- 2. Use a 5/16 nut driver to loosen all the bolts on the faceplate.
- 3. Firmly pull on the BOTTOM CENTER BOLT closest to the dB label to remove the faceplate.
- 4. Inspect the housing for debris, water migration and the rubber gasket's groove.
- 5. Inspect the replacement faceplate for proper RFI gasket and rubber gasket.
- 6. Firmly press the replacement faceplate into the housing.
- 7. Tighten the four faceplate bolts in the order numbered on the image below (bottom, then top, then left, then right) to 40 in-lbs.
- 8. Re-install the house drops to 30 in-lbs.

Material Requirements


Contents of Package


 MGT2000-SE-G2 Series Milenium Series Multi-tap


Tools and Hardware Not Included

- Cable preparation/splicing tools
- · Coaxial cable connector
- 5/16 nut driver
- 30 in. lb. torque wrench

*See www.antronix.com/resources for pedestal installation information.











Multi-tap Housing

