

# Installation Instructions Pedestal Multi-tap

**ANTRONIX®**

## Prepare the Tap for Installation

1. Remove hex port plugs and yellow port covers from the tap housing.
2. Loosen seizure screws.
3. Insert a screwdriver through the house base aperture and pivot the seizure mechanism 90 (degree sign) so that the mechanism screws are accessible through each in-line port.
4. Cut the connector pin to 1<sup>1</sup>/<sub>4</sub> in. using the trim guide on the tap housing.
5. Install the front portion of the pin connector into the tap housing and hand tighten.
6. Complete tightening with an adjustable wrench for a 1/8 to 1/4 turn.
7. Tighten the seizure screws to 15 in-lbs.
8. Replace the hex port plugs and tighten to 45 in-lbs.

## Pedestal Installation

1. Loosen the strand clamp assembly.
2. Slide shrink boot over cables if applicable.
3. Position cables and tighten strand clamp onto pedestal mounting bracket to 70 in-lbs.
4. Prep the cables for installation according to the manufacturer's specification.
5. Complete installation of the cable connector's body assembly onto the 5/8 x 24 main cable ports by tightening according to the manufacturer's instruction.
6. If applicable, slide shrink boot over the entry connector until it touches main part of housing and shrink per manufacturer's guidelines.

## Material Requirements

### Contents of Package

- MGT2000-SE-G2 Series Milenium Series Multi-tap

### Tools and Hardware Not Included

- Cable preparation/splicing tools
- Coaxial cable connector
- 5/16 nut driver
- 30 in. lb. torque wrench

